

ATEC302

TE Temperature Controller



Reference Manual


Rev 1.10

Mar, 2018

AccuThermo Technology Corp.








Table of Content

| | | |
|----|----------------------------------------------------------------------------------------------------------|-----|
| 1. | Introduction..... | 3 |
| | 1.1 Using Manuals | 4 |
| 2. | System Overview | 5 |
| | 2.1 System Configuration Overview..... | 5 |
| | 2.2 Panel Dimension & Cutout | 6 |
| | 2.3 Front Panel Description | 6 |
| | 2.4 Back Panel Wiring Diagram | 7 |
| | 2.5 USB Wiring & Color Code..... | 7 |
| | 2.6.1 Sensor Type & Measurement Range..... | 7 |
| | 2.6.2 Sensor Type & Dip-switch setting | 9 |
| | 2.7 Menu (Parameters) Overview | 9 |
| | 2.8 Error Message & Troubleshooting..... | 9 |
| | 2.9 Power Input..... | 10 |
| 3. | Front Panel Operation | 11 |
| | 3.1 Push Buttons  | 11 |
| | i. Return to Top Level Display..... | 11 |
| | ii. Go to Menu Mode..... | 11 |
| | iii. Select Parameters in Menu..... | 11 |
| | iv. Changing Parameter value | 11 |
| | 3.2 Power UP Display Sequence..... | 12 |
| | 3.3 Change the SV (Set Value) Number | 12 |
| 4. | Parameters Description | 12 |
| | 4.1 Communication Protocol | 12 |
| | 4.1.1 Communication Method | 12 |
| | 4.1.2 Communication Protocol Format..... | 13 |
| | 4.1.3 Communication Read/Write Format | 13 |
| | 4.1.4 Prior to Writing Your Own Software | 15 |
| | 4.2 Read Only Parameters [x03] Table | 15 |
| | 4.3 Read[x03]/Write[x06] Parameter Table | 18 |
| | 4.4 Error Read Back Parameter Table..... | 23 |
| 5. | Control Method..... | 24 |
| | 5.1 PID Control:..... | 24 |
| | 5.2 Auto-tune Function: | 24 |
| | 5.3 Programmable Step Control Profile:..... | 256 |
| | 5.4 Alarm Function: | 267 |
| 6. | SPECIFICATIONS | 28 |

1. Introduction

This manual contains information for the installation, operation and tuning of your Accuthermo ATEC302 TE Panel Temperature Controller, ATEC402 Din-Rail TE Temperature Controller and FTX700 High Power TE Amplifier/Driver. ATEC302 can also be connected to FTX300 or FTX100 H-bridge amplifiers.

| | | | |
|------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ATEC302 TE Panel Controller | ATEC402 (alpha ver.) TE Din-rail Controller | FTX700D TE Amplifier/Driver | FTX100/FTX300 TE H-bridge Amp |
| Pic  | Pic  | Pic  |  FTX100(6Amp)  FTX300 (12Amp) |
| RS232/RS485/USB | USB/RS485 | 5~36Vdc (30Amp) | X100:0~7V, X300:7~15V |

The Accuthermo microprocessor controllers are FUZZY ENHANCED “proportional + integral + derivative” (PID) controllers that come in with industry standard DIN72x72mm and Din-Rail size. The input is configurable and allows selection of input between thermocouples, RTD and Thermistor*.

The TE Amplifier is capable of running up to 700Watt of power. It is a very efficient TE power amplifier. The amplifier can run without force air (fan) under 350Watt in ambient condition. Over 350Watt, it is recommended to add in fan for proper ventilation.

The controller can talk to PC through a dedicated USB cable or a RS232 communication daughter card (option on ATEC302) that Accuthermo provides. And it comes with very sophisticated PC software for FREE.

The controllers can also be serial linked together and talk to one PC by using RS-485 communication method (option on ATEC302, default on ATEC402).

Caution: When USB cable is connected to the controller, the RS232 or RS485 communication daughter card should not be plugged inside the controller. Otherwise, it will have conflict.

1.1 Using Manuals

There are three manuals for this system:


Reference Manual (this one): The manual is designed for user who wants to use the front panel buttons to controller the system. The users who want to write their own program to control the system. It provides the instructions of how to use the front panel buttons, the parameter table. Users are encouraged to read the following two manuals first.

TE Temperature Controller System Installation Guild: This is the must read document for user to putting the system together. It is a step-by-step guide, with lots of pictures for easy reading.


Software Installation Guild & User Manual: The software contains a very completed function sets for user to change parameters; control and run the system; monitor and logging data. It took us more than a year to design and develop the software. More than 95% of the users find the software can satisfied their task without re-writing their own software.

2. System Overview


2.1 System Configuration Overview



2.2 Panel Dimension & Cutout



2.3 Front Panel Description



LED Indication:

KLK keypad Lock: when keyboard is locked, the push bottom is not accessible, only working through the software communication. LED lights on when keypad is enable.

PGR Program Ramp: LED lights on when temperature is ramping up/down.

PGS Program Soak: LED lights on when temperature is at soaking stage.

ENB Controller Enable: LED lights on when controller sent the Enable signal to the amplifier.


DIR Controller Hot/Cold Direction: LED indicator for the hot/cold direction command signal.

PWM Pulse Width Modulation Signal: LED signal lighted when PWM signal is send from controller to amplifier. During the low duty cycle, the LED might not be bright enough for visual.


AL1 Alarm #1 indicator: LED on when Alarm #1 is triggered.

AL2 Alarm #2 indicator: LED on when Alarm #2 is triggered.

2.4 Back Panel Wiring Diagram



2.5 USB Wiring & Color Code



Caution: If the USB cable has extra wire with RED (+5V) and Black (GND), user should either cut them off (recommended) or isolate those leads. Otherwise, possible electric short could happen.

2.6.1 Sensor Type & Measurement Range

There are three types of sensors supported by the TE Panel controllers

Thermocouple (TC): Thermocouple is a 2-wire temperature sensor and has polarity for each wire. Please follow the installation guide for proper connections. Accuracy: $\pm 1^\circ\text{C}$

| TYPE | Range |
|------|--------------------|
| J | -120.0°C ~ 200.0°C |
| K | -120.0°C ~ 200.0°C |
| T | -120.0°C ~ 200.0°C |

Thermistor (TR): Thermistor is a resistance based temperature sensor and does not have polarity.

| TYPE | Range |
|------------------|-------------------|
| TR1 (2.252K ohm) | -50.0°C ~ 150.0°C |
| TR2 (10K ohm) | -20.0°C ~ 150.0°C |

RTD PT-100 (PT): These can be 2-wire or 3-wire RTD sensors. If 2-wire is used, just short the pin7 & pin8 (PTB) together. Accuracy: $\pm 0.2^{\circ}\text{C}$

| TYPE | Range |
|------------|--------------------|
| DPT(PT100) | -120.0°C ~ 200.0°C |


2.6.2 Sensor Type & Dip-Switch Setting

| | SW1.1 | SW1.2 | SW1.3 | SW2.1 | SW2.2 |
|----|-------|-------|-------|-------|-------|
| TC | ON | OFF | OFF | ON | ON |
| PT | ON | OFF | OFF | OFF | ON |
| TR | OFF | ON | ON | OFF | OFF |

There is a Dip-Switch at the inside of the controller. The user needs to pull out the controller from back case. There are two blue-color Dip-Switch. Adjust the on/off setting according to the sensor type you want to use. Example: TR: Thermistor 2252 or 10k ohm – SW1:OFF-ON-ON, SW2:OFF-OFF



1. Pull out the Panel Cover




2. Sensor Setting Switch

Note: The yellow circles are the Dip-Switches and Switch setting table, the red circle showing the communication daughter card (either for RS232 or RS485) position.

Caution: if USB cable is used, the communication card (red circle area) should have no card plug in. Remove the plug-in card if user wants to use USB communication cable.

2.7 Menu (Parameters) Overview

Refer to Sec. 4.3 Parameter Table (Page 18) for Front Panel operation instruction



2.8 Error Message & Troubleshooting

| Symptom | Probable | Solution |
|-------------------|------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| PV value flashing | -Input signal below the low limit -Incorrect input sensor selection | -Set a higher value to high limit. -Check connect input sensor selection. |
| PV value flashing | -Input signal below the low limit -Incorrect input sensor selection | -Set at lower value to low limit. -Check correct input sensor selection |
| oPEr | -Sensor break error -Sensor not connected | -Replace sensor -Check the sensor is connected correctly |
| AdEr | -A/D converter damage | -Unit must be repaired or replaced. -Check for outside source of damage such as transient voltage spikes. |


| | | |
|----------------------------------|----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Keypad no function | -Keypads are locked, -When key locked, LED is off. | -Set "LoCK" to a proper value -If you lock the keypads, you can only use our PC software to unlock it (page. 16) |
| Process value unstable | -Improper setting of Pb, Ti, Td and CT | -Start AT process to set Pb, Ti, Td automatically -Set Pb, Ti, Td manually |
| No heat/cold or output | -No heater/cold power -Output device defective or incorrect output used | -Check output wiring and fuse -Replace output device |
| All LED's and display not light | -No power to controller | -Check power lines connection |
| Process Value changed abnormally | -Electromagnetic Interference (EMI) or Radio Frequency Interference (RFI) | -Suppress arcing contacts in system to eliminate high voltage spike sources. Separate sensor and controller wiring from "dirty" power lines. Ground heaters |
| Entered data lost | -Fail to enter data to EEPROM | -Update EEPROM again |

2.9 Power Input

The default setting is 9V-36V DC. There is a jumper inside the controller that you can set it for a fixed 5VDC. When using 5VDC as supply, the USB cable CANNOT work.

When using 5V setup. Not only change the 5V jumper position; there are two components next to jumper R111 and D101 needed to be shorted. Otherwise, they would affect the voltage drop of 5V.

If the R111 and D101 are shorted, the 'Input power reverse protection' is no longer working. Please be very caution on it. If that was damaged, it won't be covered by our standard warranty.



If the jumper has converted for 5VDC, connecting to supply power other than 5V will damage the system; and the warranty is void.




3. Front Panel Operation

User should learn some front panel operation during hardware installation. This section will describe more in detail.





3.1 Push Buttons


Referring to 2.4 Menu Overview, users can select different level of menu and change the parameters using these four push buttons.

i. Return to Top Level Display

If you make mistake, just press  &  two buttons, it will return to top level display  for normal operation.



ii. Go to Menu Mode

Press and hold  two buttons for 5 seconds, the screen will jump to menu mode. The RED LED line should show . It is the first level menu. By pressing  button, user can select various top menus in sequence, using  button to select the previous menu.







Note: If keypads are locked, you can only run our PC software to unlock it (page. 16)

iii. Select Parameters in Menu

The parameters selection in each menu is in a loop format. At each top menu, press  button to select its parameters. If you miss it, just press  continuously until it reaches the parameter you are looking for.

iv. Changing Parameter value

The parameter is Number (ex. temperature): To change a parameter value, press  to select the digit you





want to change, the specific digit LED should be highlighted. Then press  to add number or  to reduce the number. Press  to confirm the value.

The parameter is Type (ex. sensor type): Use  or  buttons to choose the desire one.

3.2 Power UP Display Sequence

When power up the controller, the display will show from Top/Bottom display in sequence:
LED all on test → Sensor type/Temperature unit → High Limit/Low Limit
→ PV(process value)/SV(set value)

3.3 Change the SV (Set Value) Number

- i. Use  to highlight the digit you want to change.
- ii. Use  or  buttons to change to the value desired.
- iii. Press  to confirm the value.

4. Parameters Description

4.1 Communication Protocol

4.1.1 Communication Method

One controller to one PC: There is a special USB data cable supplied by Accuthermo. It is a serial-to-USB data converter. While connecting a PC and the controller with this cable, the software Accuthermo supplied will work on this setup.

Multiple controllers to one PC: By serialized multiple controllers together through the RS485 lines (TX+/ TX-). A PC act as a master and talk to those controllers as slave units. Each controller should have a unique ID address number. We recommend a RS485-to-USB converter act as a

communication agent between PC and controllers. The software supplied by Accuthermo cannot talk to multiple controllers; only one at a time with proper ID address selected.

4.1.2 Communication Protocol Format

| RS232/ RS485-Modbus RTU | |
|-------------------------|-----------|
| Party | None |
| Data bit | 8 Bit |
| Stop bit | 1 Bit |
| Baud rate | 19200 bps |
| CRC16 | YES |

4.1.3 Communication Read/Write Format

| | |
|----------------------------|-----------------------------|
| Read Command Code: hex x03 | Write Command Code: hex x06 |
|----------------------------|-----------------------------|

Each time a command is sent from the master (ex. Computer) to the controller, the controller receives should immediately response a similar message back to its master. For example:

SEND: The PC send a command set (total of 8 bytes) asking for the temperature that was just measured: x01-03-1000-0001-CCCC

RETURN: The slave unit (controller) returned an 8-bytes data to its master:

x01-03-0002-01F7-CCCC. Where “x01F7” is the temperature measured in Hex format (=50.3°C); where “x” means hex format, “C” means CRC data.

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|----|--------------|------------------------------------|---|--------------------|---|---------|---|
| Represent | ID | R/W Function | Parameter Address or Byte count | | Data Cnt Or Rtn | | CRC | |
| Byte Count | 1 | 1 bytes | 2 bytes | | 2 bytes | | 2 bytes | |

Byte 1 – ID: It is the ID number of the controller, the default is 1.

Byte 2 – R/W Function: Read function is hex number x03, Write function is hex number x06

Byte 3,4 – Parameter Address or Return Byte Count: See the following example and description for detail.

Byte 5,6 – Data/Data Count/Data Return Count. The 2 bytes have different meanings during the read-send/return. For write process, the send return should have the same value.

Byte 7,8 – Modbus CRC: 16bits Cyclic Redundancy Check is done to prevent corrupted data during communication transmission. It takes the first known command bytes through a CRC calculation and generates the 2-CRC bytes at the end.

Write Process Example:

During the write process the response bytes should match the command set.

Master ask the controller to set the SV temperature at 55.0°C

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|-----|--------------|-------------------|---|---------|---|---------|---|
| Represent | ID | R/W Function | Parameter Address | | Data | | CRC | |
| Byte Count | 1 | 1 bytes | 2 bytes | | 2 bytes | | 2 bytes | |
| | x01 | x06 | x0000 | | x0226 | | xCCCC | |

Response from the controller

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|-----|--------------|-------------------|---|---------|---|---------|---|
| Represent | ID | R/W Function | Parameter Address | | Data | | CRC | |
| Byte Count | 1 | 1 bytes | 2 bytes | | 2 bytes | | 2 bytes | |
| | x01 | x06 | x0000 | | x0226 | | xCCCC | |

Read Process Example:

During the read process, you can ask for one data back, or you can ask a set of data back in sequence. The byte 3-4 is the initial parameter address. The byte 5-6 is to tell slave how many consecutive data you want. The following example only asks for one data.

The master ask the controller to read current temperature (PV value)

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|-----|--------------|-------------------|---|----------|---|---------|---|
| Represent | ID | R/W Function | Parameter Address | | Data Cnt | | CRC | |
| Byte Count | 1 | 1 bytes | 2 bytes | | 2 bytes | | 2 bytes | |
| | x01 | x03 | x1000 | | x0001 | | xCCCC | |

In the response data set, the byte 3-4 is the byte count of the data return. The following example is the response data from above command. The byte 3-4 tell the master it has 2 bytes of data. The content of the return data is at byte 5-6.


Response from the controller (measured 28.7°C)

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|-----|--------------|------------|---|----------|---|---------|---|
| Represent | ID | R/W Function | Byte Count | | Data Rtn | | CRC | |
| Byte Count | 1 | 1 bytes | 2 bytes | | 2 bytes | | 2 bytes | |
| | x01 | x03 | x0002 | | x011F | | xCCCC | |

Note: Byte Count value = 2 x Data Count value

4.1.4 Prior to Writing Your Own Software

Most users will find the software come with the system should work just fine. There are about 5% engineers need to write their own software to integrate with other hardware. To better understand how the parameters work, Please use the Protocol Section of the software that Accuthermo supplied. You can then try out all the parameters in tables of 4.2 and see how they interacting each other.



Refer to top right pic; the protocol page of Accuthermo PC software. After read PV and converted to DegC, it shown 19.7C, and should be the same as value showing on the front panel of the ATEC302 controller. To read PV (process value = your sensor temperature), we use "\01\03\10\00\00\01\80\CA" (Hex code) to send to controller. Here is the explanation of those 8 bytes:

- First byte \01: the controller address.
- Second byte \03: to read from the controller (\06 is to write to the controller). In this case, you want to read PV from the controller.
- 3&4 byte \10\00: the x1000 is to read PV+PV-offset value together. In most of the case, the PV-offset is 0 (unless changed by user). So you are reading the PV value.
- 5&6 byte \00\01: For READ process, these two bytes does not do anything, so we just put two dummy bytes here.
- 7&8 byte \80\CA: The two byte CRC value after calculate the prior 6 bytes of data(\01\03\10\00\00\01).

Since read PV is a fixed value in this case, you can just write all 8 bytes showing above. You don't have to calculate CRC every time for Reading PV command.

4.2 Read Only Parameters [x03] Table

Read Only Parameters: Read parameter and value from the controller

| Address | Parameter Name | Contents | Unit |
|---------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| x1000 | PVPVOF | PV + PVOF | °C/°F/ ENG |
| x1001 | SVSVOF | SV + SVOF | °C/°F/ ENG |
| x1002 | OUTL | Output Power in Percentage | % |
| x1003 | WKERNO | <p>x ___ 0 Alarm2 Off , Alarm1 Off x ___ 1 Alarm2 Off , Alarm1 On x ___ 2 Alarm2 On , Alarm1 Off x ___ 3 Alarm2 On , Alarm1 On</p> <p>x 0 0 0 _ ENB ,DIR ,PWM Output Off</p> <p><i>(Autotune type 1: x010_ ~ x015_ use SV as target temperature)</i> x 0 1 0 _ Autotune SV initial x 0 1 1 _ Autotune SV start ramping x 0 1 2 _ Autotune SV the first positive half cycle x 0 1 3 _ Autotune SV the first negative half cycle x 0 1 4 _ Autotune SV the second positive half cycle x 0 1 5 _ Autotune SV P.I.D in analyzing and calculating <i>(Autotune type 2: x020_ ~ x025_ use SV × 90% as target temperature)</i> x 0 2 0 _ Autotune 90% SV initial x 0 2 1 _ Autotune 90% SV start ramping x 0 2 2 _ Autotune 90% SV the first positive half cycle x 0 2 3 _ Autotune 90% SV the first negative half cycle x 0 2 4 _ Autotune 90% SV the second positive half cycle x 0 2 5 _ Autotune 90% SV P.I.D in analyzing and calculating</p> <p>x 0 3 0 _ Manual Output x 0 4 0 _ General Control (single point temperature control)</p> <p><i>Programmable step temperature control (multipoint temperature control)</i></p> <p>x 0 5 0 _ Program control Ramp 1 x 0 5 1 _ Program control Hold 1 x 0 5 2 _ Program control Ramp 2 x 0 5 3 _ Program control Hold 2 x 0 5 4 _ Program control Ramp 3 x 0 5 5 _ Program control Hold 3 x 0 5 6 _ Program control Ramp 4 x 0 5 7 _ Program control Hold 4 x 0 5 8 _ Program control Ramp 5 x 0 5 9 _ Program control Hold 5 x 0 5 A _ Program control Ramp 6 x 0 5 B _ Program control Hold 6 x 0 5 C _ Program control Ramp 7 x 0 5 D _ Program control Hold 7 x 0 5 E _ Program control Ramp 8 x 0 5 F _ Program control Hold 8 x 0 6 0 _ Hold (pause) Program control</p> <p>x 1 0 0 _ Error Message OPER (Error sensor input is OPEN) x 2 0 0 _ Error Message ADER (Error in A/D converting) x 3 0 0 _ Error Message EPER (memory error) x 4 0 0 _ Error Message ATER (auto tune error) x 5 0 0 _ Error Message HIER (PV higher than HILT) x 6 0 0 _ Error Message LOER (PV lower than LOLT)</p> | Code |
| x1004 | RAMP_TL | Tim passed at script programming during ramping or soaking | Sec/Min |

| | | | |
|-------|-----------|------------------------------------------------|------------|
| x1005 | RAMP_TH | | |
| x1006 | ALM1_TL | Time left when using delay alarm | Sec/Min |
| x1007 | ALM1_TH | | |
| x1008 | SV0 | SV + SVOF (fixed 1 decimal point) | °C/°F/ ENG |
| x1009 | PV0 | PV value (fixed 1 decimal point) | °C/°F/ ENG |
| x100A | PV1 | PV history value1 (fixed 1 decimal point) | °C/°F/ ENG |
| x100B | PV2 | PV history value2 (fixed 1 decimal point) | °C/°F/ ENG |
| x100C | ET0 | SV - Pv value (fixed 1 decimal point) | °C/°F/ ENG |
| x100D | ET1 | SV - PV history value1 (fixed 1 decimal point) | °C/°F/ ENG |
| x100E | ET2 | SV - PV history value2 (fixed 1 decimal point) | °C/°F/ ENG |
| x100F | Px | Proportional factor | % |
| x1010 | Ix | Integral factor | Sec |
| x1011 | Dx | Differential factor | Sec |
| x1012 | MRx | MR factor | % |
| x1013 | ARx | AR factor | % |
| x1014 | Pout | Proportional output % | % |
| x1015 | Iout | Integral output % | % |
| x1016 | Dout | Differential output % | % |
| x1017 | Pband | Proportional band | °C/°F/ ENG |
| x1018 | ARW | Integral band | °C/°F/ ENG |
| x1019 | LEVEL | | Code |
| x101A | AD0 | A/D 0 after filter Count | Count |
| x101B | AD1 | A/D 1 after filter Count | Count |
| x1F00 | VER | Hardware & Firmware version | Code |
| x1F01 | SERIAL_NH | Product Model number | Code |
| x1F02 | SERIAL_NL | | |

4.3 Read[x03]/Write[x06] Parameter Table

Read/Write-able Parameters: The following parameter's data can be changed or just be read out without change.

| Address | Naming | Range | Init Value | Unit |
|---------|--------|------------------------------------------------------|------------|------------|
| x0000 | SV | LOLT ~HILT | 20.0 | °C/°F |
| x0001 | OUTL | -100.0 ~ 100.0 | 0.0 | % |
| x0002 | ENAB | x0000 / OFF (Turn off output) | OFF | Index Code |
| | | x0001 / AT1 (auto-tune at SV) | | |
| | | x0002 / AT2 (auto-tune at 90% of SV) | | |
| | | x0003 / MPWR (Manual set duty cyl) | | |
| | | x0004 / SPON (Single Temp point ctrl) | | |
| | | x0005 / PROG (Run Programmable temp profile) | | |
| | | x0006 / HOLD (Hold Temp during prog profile run) | | |
| x0003 | PB1 | 0.00 ~ 300.00 | 5.0 | % |
| x0004 | TI1 | 0 ~ 4500 | 240 | 100mSec |
| x0005 | TD1 | 0~ 1125 | 60 | 100mSec |
| x0006 | MR1 | 0.0 ~ 51.0 | 0.0 | % |
| x0007 | AR1 | 0.0 ~ 100.0 | 50.0 | % |
| x0008 | ASP1 | LOLT ~HILT (region-1 PID range ex. <0~50.0C) | 50.0 | °C/°F |
| x0009 | PB2 | 0.00 ~ 300.00 | 5.0 | % |
| x000A | TI2 | 0 ~ 4500 | 240 | 100m Sec |
| x000B | TD2 | 0~ 1125 | 60 | 100m Sec |
| x000C | MR2 | 0.0 ~ 51.0 | 0.0 | % |
| x000D | AR2 | 0.0 ~ 100.0 | 50.0 | % |
| x000E | ASP2 | LOLT ~HILT (region-2 PID range ex. <50.1~100.0C) | 100.0 | °C/°F |
| x000F | PB3 | 0.00 ~ 300.00 | 5.0 | % |
| x0010 | TI3 | 0 ~ 4500 | 240 | 100m Sec |
| x0011 | TD3 | 0~ 1125 | 60 | 100m Sec |
| x0012 | MR3 | 0.0 ~ 51.0 | 0.0 | % |
| x0013 | AR3 | 0.0 ~ 100.0 | 50.0 | % |
| x0014 | ASP3 | LOLT ~HILT (region-3 PID range ex. <100.1~150.0C) | 150.0 | °C/°F |
| x0015 | PB4 | 0.00 ~ 300.00 | 5.0 | % |
| x0016 | TI4 | 0 ~ 4500 | 240 | 100m Sec |
| x0017 | TD4 | 0~ 1125 | 60 | 100m Sec |
| x0018 | MR4 | 0.0 ~ 51.0 | 0.0 | % |
| x0019 | AR4 | 0.0 ~ 100.0 | 50.0 | % |
| x001A | A1SP | LOLT ~HILT (Alarm 1 set point) | 100.0 | °C/°F |
| x001B | A1HY | -200.0 ~ 200.0 (value for alarm region or delta-t) | 0.0 | °C/°F |
| x001C | A1FU | x0007 / OFF (alarm not activate) | OFF | Index Code |
| | | x0008 / HI (alarm on when >A1SP) | | |
| | | x0009 / LO (alarm on when <A1SP) | | |
| | | x000A / DIFH (alarm on when >delta) | | |
| | | x000B / DIFL (alarm on when <delta) | | |
| | | x000C / BDHI (alarm on when out off region) | | |
| | | x000D / BDLO (alarm on when PV within region) | | |
| x001D | A1MD | x000E / NONE (Alarm run in normal condition) | NONE | Index Code |
| | | x000F / STDY (Ignore first alarm) | | |
| | | x0010 / LATH (turn alarm on when latch) | | |

| | | | | | |
|-------------------------------------|------|------------------------------------------------------------------------|-------|------------|--------------------|
| | | x0011 / STLA (Ignore first alarm and turn next alarm on when latch) | | | |
| x001E | A1DT | 9999 ~ 0 (delay time to turn alarm on) | 0 | Sec/Min | |
| x001F | A1AB | x0012 / ALNO (alarm normal open_L ,when latch turn H) | ALNO | Index Code | |
| | | x0013 / ALNC(alarm normal close_H ,when latch turn L) | | | |
| x0020 | A1ER | x0014 / NONE (controller keep running if alarm is latch) | NONE | Index Code | |
| | | x0015 / STOP (controller off if alarm is latch) | | | |
| | | | | | |
| x0021 | A2SP | LOLT ~HILT (Alarm 2 set point) | 100.0 | °C/°F | |
| x0022 | A2HY | -200.0 ~ 200.0 (value for alarm region or delta-t) | 0.0 | °C/°F | |
| x0023 | A2FU | x0007 / OFF (alarm not activate) | OFF | Index Code | |
| | | x0008 / HI (alarm on when >A2SP) | | | |
| | | x0009 / LO (alarm on when <A2SP) | | | |
| | | x000A / DIFH (alarm on when >delta) | | | |
| | | x000B / DIFL (alarm on when <delta) | | | |
| | | x000C / BDHI (alarm on when out off region) | | | |
| | | x000D / BDLO (alarm on when PV within region) | | | |
| x0024 | A2MD | x000E / NONE (Alarm run in normal condition) | NONE | Index Code | |
| | | x000F / STDY (Ignore first alarm) | | | |
| | | x0010 / LATH (turn alarm on when latch) | | | |
| | | x0011 / STLA (Ignore first alarm and turn next alarm on when latch) | | | |
| x0025 | A2DT | 9999 ~ 0 (delay time to turn alarm on) | 0 | Sec/Min | |
| x0026 | A2AB | x0012 / ALNO(alarm normal open_L ,when latch turn H) | ALNO | Index Code | |
| | | x0013 / ALNC(alarm normal close_H ,when latch turn L) | | | |
| x0027 | A2ER | x0014 / NONE (controller keep running if alarm is latch) | NONE | Index Code | |
| | | x0015 / STOP (controller off if alarm is latch) | | | |
| | | | | | |
| X0028 | TYPE | x0016 / J | TR1 | Index Code | |
| | | x0017 / K | | | |
| | | x0018 / T | | | |
| | | x0019 / DPT | | | |
| | | x001A / TR1 (2.252K) | | | |
| | | x001B / TR2 (10K) | | | |
| | | x0037 / mA (option* of new firmware) | | | |
| | | x0038 / mV (option* of new firmware) | | | |
| X0039 / V (option* of new firmware) | | | | | |
| x0029 | UNIT | x001C / °C | °C | Index Code | |
| | | x001D / °F | | | |
| | | x003E / ENG | | | |
| x002A | DP | x001E / 0000. (no decimal pt) | DP 1 | Index Code | |
| | | x001F / 000.0 (one decimal pt) | | | |
| | | x003F / 00.00 (two decimal pt, option* of new firmware) | | | |
| | | x0040 / 0.000 (three decimal pt, option* of new firmware) | | | |
| x002B | DIR | x0020 / REV (TE output direction rev) | REV | Index Code | |
| | | x0021 / FWD (TE output direction forward) | | | |
| x002C | LOLT | TYPE | 0.0 | °C/°F | |
| | | Range | | | |
| | | J /K /T | | | -70.0°C ~ 200.0°C |
| | | DPT | | | -70.0 °C ~ 200.0°C |
| | | TR1 | | | |
| | | -30.0 °C ~ 150.0°C | | | |

| | | | | | |
|------------------------------------|------|-----------------------------------------------------------------------------------------------|--------------------|-------|-------------|
| | | TR2 | -10.0 °C ~ 150.0°C | | |
| x002D | HILT | Same as LOLT parameters | | 200.0 | °C/°F |
| x002E | TUNT | x0022 / Sec (controller time unit in sec) | | Sec | Index Code |
| | | x0023 / Min (controller time unit in min) | | | |
| x002F | EROP | (Select output operation when alarm latch) x0024 / 00 (Alarm1 & Alarm2 OFF, PWM & ENB OFF) | | 00 | Index Code |
| | | x0025 / 01 (Alarm1 ON, Alarm2 OFF, PWM & ENB ON) | | | |
| | | x0026 / 10 (Alarm1 ON, Alarm2 ON, PWM & ENB OFF) | | | |
| | | x0027 / 11 (Alarm1 ON, Alarm2 ON, PWM & ENB OFF) | | | |
| x0030 | SPOF | -200.0 ~ 200.0 (set-point offset) | | 0.0 | °C/°F |
| x0031 | PVOF | -200.0 ~ 200.0 (process-value offset) | | 0.0 | °C/°F |
| x0032 | FILT | 0.0 ~ 99.9 (noise filter, larger value filter noise better but delay process operation) | | 0.0 | Coefficient |
| x0033 | ID | 255 ~ 1 (controller ID address) | | 255 | address |
| x0034 | STAT | x0028 / OFF (don't save position) | | OFF | Index Code |
| | | x0029 / ON (save current position) | | | |
| x0035 | STAR | x002A / ZERO (run program start SV-t from 0C) | | PV | Index Code |
| | | x002B / PV (run program start SV-t from current PV) | | | |
| x0036 | BAND | 0.0 ~ 200.0 | | 20.0 | °C/°F |
| x0037 | RT1 | 0 ~ 9999 (Ramp Time) | | 60 | Sec/Min |
| x0038 | SP1 | LOLT ~HILT (1 st Set Point Value) | | 20.0 | °C/°F |
| x0039 | ST1 | 0 ~ 9999 (1 st SP Sock Time) | | 60 | Sec/Min |
| x003A | SF1 | x002C / RT8 (after ST time jump to RT8) | | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | | |
| | | x002E / RT6 (after ST time jump to RT6) | | | |
| | | x002F / RT5 (after ST time jump to RT5) | | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | | |
| | | x0034 / END (After prog turn off output) | | | |
| | | x0035 / HOLD (After prog hold temperature) | | | |
| x0036 / NEXT (After prog goto RT2) | | | | | |
| x003B | LN1 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | | 1 | count |
| x003C | RT2 | 0 ~ 9999 | | 60 | Sec/Min |
| x003D | SP2 | LOLT ~HILT | | 20.0 | °C/°F |
| x003E | ST2 | 0 ~ 9999 | | 60 | Sec/Min |
| x003F | SF2 | x002C / RT8 (after ST time jump to RT8) | | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | | |
| | | x002E / RT6 (after ST time jump to RT6) | | | |
| | | x002F / RT5 (after ST time jump to RT5) | | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | | |
| | | x0034 / END (After prog turn off output) | | | |
| | | x0035 / HOLD (After prog hold temperature) | | | |
| x0036 / NEXT (After prog goto RT3) | | | | | |
| x0040 | LN2 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | | 1 | count |

| | | | | |
|------------------------------------|-----|------------------------------------------------------------|------|------------|
| x0041 | RT3 | 0 ~ 9999 | 60 | Sec/Min |
| x0042 | SP3 | LOLT ~HILT | 20.0 | °C/°F |
| x0043 | ST3 | 0 ~ 9999 | 60 | Sec/Min |
| x0044 | SF3 | x002C / RT8 (after ST time jump to RT8) | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | |
| | | x002E / RT6 (after ST time jump to RT6) | | |
| | | x002F / RT5 (after ST time jump to RT5) | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | |
| | | x0034 / END (After prog turn off output) | | |
| | | x0035 / HOLD (After prog hold temperature) | | |
| x0036 / NEXT (After prog goto RT4) | | | | |
| x0045 | LN3 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | 1 | count |
| x0046 | RT4 | 0 ~ 9999 | 60 | Sec/Min |
| x0047 | SP4 | LOLT ~HILT | 20.0 | °C/°F |
| x0048 | ST4 | 0 ~ 9999 | 60 | Sec/Min |
| x0049 | SF4 | x002C / RT8 (after ST time jump to RT8) | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | |
| | | x002E / RT6 (after ST time jump to RT6) | | |
| | | x002F / RT5 (after ST time jump to RT5) | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | |
| | | x0034 / END (After prog turn off output) | | |
| | | x0035 / HOLD (After prog hold temperature) | | |
| x0036 / NEXT (After prog goto RT5) | | | | |
| x004A | LN4 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | 1 | count |
| x004B | RT5 | 0 ~ 9999 | 60 | Sec/Min |
| x004C | SP5 | LOLT ~HILT | 20.0 | °C/°F |
| x004D | ST5 | 0 ~ 9999 | 60 | Sec/Min |
| x004E | SF5 | x002C / RT8 (after ST time jump to RT8) | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | |
| | | x002E / RT6 (after ST time jump to RT6) | | |
| | | x002F / RT5 (after ST time jump to RT5) | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | |
| | | x0034 / END (After prog turn off output) | | |
| | | x0035 / HOLD (After prog hold temperature) | | |
| x0036 / NEXT (After prog goto RT6) | | | | |
| x004F | LN5 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | 1 | count |
| x0050 | RT6 | 0 ~ 9999 | 60 | Sec/Min |
| x0051 | SP6 | LOLT ~HILT | 20.0 | °C/°F |
| x0052 | ST6 | 0 ~ 9999 | 60 | Sec/Min |
| x0053 | SF6 | x002C / RT8 (after ST time jump to RT8) | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | |
| | | x002E / RT6 (after ST time jump to RT6) | | |
| | | x002F / RT5 (after ST time jump to RT5) | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | |

| | | | | |
|-------|------|------------------------------------------------------------|---------|------------|
| | | x0031 / RT3 (after ST time jump to RT3) | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | |
| | | x0034 / END (After prog turn off output) | | |
| | | x0035 / HOLD (After prog hold temperature) | | |
| | | x0036 / NEXT (After prog goto RT7) | | |
| x0054 | LN6 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | 1 | count |
| x0055 | RT7 | 0 ~ 9999 | 60 | Sec/Min |
| x0056 | SP7 | LOLT ~HILT | 20.0 | °C/°F |
| x0057 | ST7 | 0 ~ 9999 | 60 | Sec/Min |
| x0058 | SF7 | x002C / RT8 (after ST time jump to RT8) | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | |
| | | x002E / RT6 (after ST time jump to RT6) | | |
| | | x002F / RT5 (after ST time jump to RT5) | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | |
| | | x0034 / END (After prog turn off output) | | |
| | | x0035 / HOLD (After prog hold temperature) | | |
| x0059 | LN7 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | 1 | count |
| x005A | RT8 | 0 ~ 9999 | 60 | Sec/Min |
| x005B | SP8 | LOLT ~HILT | 20.0 °C | °C/°F |
| x005C | ST8 | 0 ~ 9999 | 60 | Sec/Min |
| x005D | SF8 | x002C / RT8 (after ST time jump to RT8) | END | Index Code |
| | | x002D / RT7 (after ST time jump to RT7) | | |
| | | x002E / RT6 (after ST time jump to RT6) | | |
| | | x002F / RT5 (after ST time jump to RT5) | | |
| | | x0030 / RT4 (after ST time jump to RT4) | | |
| | | x0031 / RT3 (after ST time jump to RT3) | | |
| | | x0032 / RT2 (after ST time jump to RT2) | | |
| | | x0033 / RT1 (after ST time jump to RT1) | | |
| | | x0034 / END (After prog turn off output) | | |
| | | x0035 / HOLD (After prog hold temperature) | | |
| x005E | LN8 | 1~9998 (x270E) Loop number Infinite loop = 9999 (x270F) | 1 | count |
| x005f | LOCK | x0028 / Keyboard Enable X0029 / Keyboard Disable | Enable | Index Code |
| X0075 | SCAL | -199.9 ~ 999.9 (option* of new firmware) | 0.0 | °C/°F/EN |
| X0076 | SCAH | -199.9 ~ 999.9 (option* of new firmware) | | |
| X0077 | CUT | x003A / NONE (linear option* of new firmware) | NONE | Index Code |
| | | x003B / LO (linear option* of new firmware) | | |
| | | x003C / HI (linear option* of new firmware) | | |
| | | x003D / HILO (linear option* of new firmware) | | |
| | | | | |
| | | | | |

4.4 Error Read Back Parameter Table

After PC talks to the controller, the controller will return bytes of info. If for some reason the controller felt there is an error, it will return Error Code.


| | | | | | | |
|----------------|-------------------------------------------------------------------------------|-------------------|-----|---------------|-----|-----|
| | ID | Function + x80 | 00 | Error code | x00 | x00 |
| Function error | xx | x8x | x00 | X01 | x00 | x00 |
| | Function error (write or read) only with x03H or x06H | | | | | |
| Address error | xx | x8x | x00 | X02 | x00 | x00 |
| | Addr error (write or read parameter addr) parameter address of x00H ~ x57H | | | | | |
| Data error | xx | x8x | x00 | X03 | x00 | x00 |
| | Data error (only write) | | | | | |

5. Control Method

5.1 PID Control:

A proportional–integral–derivative controller (PID controller) is a control loop feedback mechanism used in this temperature control. It attempts to correct the error between a measured Process Value and a desired Set-Point Value by calculating and then outputting a corrective action that can adjust the process accordingly and rapidly, to keep the error minimal.

Please use the software provided with this system to better understand the relationship of the PID and temperature control.








5.2 Auto-tune Function:

The controller has a build-in auto-tune function, it will calculate to a optimized set of PID values with the desired temperature.

AT1: use SV as the target temperature (default)


AT2: use SV × 90% as the target temperature, (slower but less overshoot)

5.3 Programmable Step Control Profile:



5.4 Alarm Function:

ALARM FUNCTION



6. SPECIFICATIONS

INPUT

| | |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Thermocouple | J, K, T(default) |
| RTD | DIN PT-100 |
| Thermistor (TR) | 2252 ohm, 10k ohm |
| Range (ATEC302 & ATEC402) | T/C J -120C ~ 200C T/C K -120C ~ 200C T/C T -120C ~ 200C RTD -120C ~ 200C TR2252 -50C ~ 150C TR10K -20C ~ 150C |
| Accuracy | ±0.1°C (*depends on sensor type and temperature range) |
| Cold Junction Compensation | 0.1°C/°C ambient |
| Normal Mode Rejection | 60 dB |
| Common Mode Rejection | 120 dB |

CONTROL FUNCTION

| | |
|--------------------------|--------------------------------------------------------------------|
| Proportional Band | 0.0 ~ 300.0 % |
| Integral Time | 0 ~ 4000 (100mSec) |
| Derivative Time | 0 ~ 1000 (100mSec) |
| Hysteresis | 0.0 ~ 200.0/ 0 ~ 2000 |
| Sampling Rate | 10Hz |
| Temperature Control Res. | 0.1°C / 0.1°F |
| Programmable Profile | 8 Steps, ramp/soak time, loop-in-loop, complex loop profile |
| Control Software | Full function Window Program, plot chart, log data, engineer debug |

OUTPUT

| | |
|--------------------|------------------------------------------------------------------------|
| Display Resolution | 0.1°C / 0.1°F(default) or 1°C / 1°F |
| Alarm Relay Output | Logic 5VDC Level (on:1 /off:0) |
| PWM Output | Logic 5VDC Level, Freq: 1K Hz |
| Enable | Logic 5VDC Level |
| H/C Control Action | Logic 5VDC Level, Direct or Reverse (for cooling or heating direction) |
| Communication | USB, Serial (logic), RS485 |

GENERAL

| | |
|---------------------|-------------------------------------------------------------|
| Rated Voltage | 9~36 VDC(default) or 5VDC jumper setting |
| Power Consumption | Less than 3VA (100mA@24VDC) |
| Memory Backup | EEPROM and non-volatile memory (Approx. 10 years) |
| Operation Condition | Temperature: 0 ~ 50°C, Humidity 0 ~ 85% RH (Non-condensing) |